	FANUC	MITSUBISHI	HEIDENHAIN	BROTHER
Overall Data (Standard)		l		
CNC Available		 	√	√
Operator Message	√	√	√	√
Emergency Stop	√	√	√	√
Axis Data		<u> </u>		
Position	√	X	✓	√
Load	√	Х	√	√
Actuator	√	Х	√	√
Temperature	√	Х	√	√
Spindle Data		<u>. </u>		
Spindle RPM	√	✓	X	X
Spindle Load	√	√	X	X
Spindle Override	√	√	Х	X
Path Data (Standard)				
Current Program Block	√	\	✓	/
Controller Mode	\	/	√	/
Pr <mark>og</mark> ram Line N <mark>umb</mark> er	√	1	X	\
Main Program	√	✓	✓	✓
Main Pro <mark>gram Comment</mark>		/		\
Execution State	✓		-	/
Tool ID	X	Х	\	/
Part Cou <mark>nt</mark>	-	/	-	/
Path Fee <mark>drate</mark>	√	√	√	√
Logic Program (PMC Alarms)	√	√	√	√
Communications (CNC Common Alarms)	√	√	√	√
Motion Program (Part Program Alarms)	√	√	√	√
System (All Other Alarms)	√	X	√	√
Active Axis	√	√	√	√
Feedrate Override	√	✓	✓	✓
Custom Points				
Data Defined in the XML				
1-Path	\checkmark	X	X	X
2-Controller	\checkmark	X	X	X
3-Device	\checkmark	X	X	X
Configurable CNC Data				
1-PMC Data	√	X	\checkmark	X
2-Custom Macro Variables	√	X	\checkmark	X

